


# LeCavist

Instruction Manual

## SINGLE-ZONE

WINE CABINET



[www.lecavist.com](http://www.lecavist.com)

MODEL: LEK14PV  
LEK21PV  
LEK33PV

# CONGRATULATIONS

Congratulations and thank you for choosing LeCavist for your wine storage solution.

This appliance complies with all relevant safety requirements in Australia. Inappropriate use can, however, lead to personal injury and damage to property.

In order to operate the unit correctly and safely, please read this instruction manual carefully before installation and use. This user manual which provides you with all required instructions related to safety, installation, use and maintenance of the appliance.

For future reference, please store this booklet in a safe place and ensure that all users are familiar with the contents. Pass them on to any future owner of the appliance.

Record Model & Serial Number

Model:.....

Serial Number .....

Register your product at [www.lecavist.com](http://www.lecavist.com)

## ! IMPORTANT

Adherence to the directions for use in this manual is extremely important for health and safety. Failure to strictly adhere to the requirements in this manual may result in personal injury, property damage and affect your ability to make a claim under the LeCavist manufacturer’s warranty provided with your product. Products must be used, installed and operated in accordance with this manual. You may not be able to claim on the LeCavist manufacturer’s warranty in the event that your product fault is due to failure to adhere this manual.

### Correct Conditions of Use

- The appliance is intended for use in the home and similar environments only. It is not intended for commercial use.
- The appliance is not suitable for outdoor use, non-stationary installation.
- This wine cooler can be only used to store various types of wines



Installation must comply with the valid standards, regulations and laws. All safety and warning information and the operating and installation instructions must be complied with.

Additional information on products, accessories, warranty, replacement parts and services can be found at [www.lecavist.com](http://www.lecavist.com)

# TABLE OF CONTENTS

|                                             |           |                                             |           |
|---------------------------------------------|-----------|---------------------------------------------|-----------|
| <b>1. General Information .....</b>         | <b>03</b> | <b>7.Care and maintenance .....</b>         | <b>07</b> |
| 1.1 Appliance information                   |           | 7.1 In case of a power cut                  |           |
| <b>2. General Safety Instructions .....</b> | <b>03</b> | 7.2 Moving your wine cabinet                |           |
| 2.1 General safety information              |           | <b>8. In the event of a breakdown .....</b> | <b>07</b> |
| 2.2 Safety instruction - Installation       |           | <b>9. Troubleshooting guide .....</b>       | <b>08</b> |
| 2.3 Correction use & Operation .....        | <b>04</b> | Replacing the light                         |           |
| 2.4 Disassembling and Disposal              |           | <b>10.Environmental tips .....</b>          | <b>09</b> |
| of the Appliance                            |           | 10.1 Disposal considerations                |           |
| 2.5 Accessories and Spare parts             |           | 10.2 Disposing your old appliance           |           |
| 2.6 Use of Extension Cord                   |           | 10.3 Caution: Risk of fire                  |           |
| <b>3.Installation instruction .....</b>     | <b>05</b> | <b>11.Warranty and After sales .....</b>    | <b>09</b> |
| <b>4.Loading plan.....</b>                  | <b>05</b> | 11.1 Warranty                               |           |
| <b>5.Drip tray.....</b>                     | <b>06</b> | 11.2 After sales service                    |           |
| <b>6.Wine Cabinet Features and Use.....</b> | <b>06</b> | 11.3 Replacement of spare parts             |           |

# 1. GENERAL INFORMATION

## 1.1 Appliance Information

- A damaged appliance can be dangerous. If you find the appliance is damaged or marked, you must report it within 7 days if you wish to claim for damage/marks under the manufacturer's warranty. This does not affect your statutory rights. Do not use a damaged appliance.
- The manufacturer's warranty will be invalidated if the appliance is not repaired by a LeCavist approved service technician.
- Faulty components must only be replaced by genuine LeCavist spare parts. The manufacturer can only guarantee the safety of the appliance when LeCavist replacement parts are used.
- If the power cord is damaged, it must only be replaced by a LeCavist authorised service technician or suitably qualified electrician in order to avoid a hazard.
- LeCavist cannot be held liable for non-compliance with these instructions, resulting from incorrect or improper use or operation.

# 2. GENERAL SAFETY INSTRUCTIONS

 The appliance complies with the stipulated safety requirements in Australia. The user is responsible for appliance cleaning and maintenance as well as its safe use. Improper use can lead to personal injury and damage to property.

## 2.1 General Safety Instructions

### Children and People with Special Needs

#### WARNING

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- The appliance is NOT suitable for use by children without supervision.
- Young children should be supervised near the appliance to ensure they do not play with this appliance.
- Children may be able to wrap themselves in packing material or pull it over their heads with the risk of suffocation. Keep children away from any packing material.

### Unauthorised Modifications

Unauthorised modifications can cause the appliance to pose risks. Do not conduct any modifications to the appliance.

### Cleaning & Maintenance

The device must be cleaned regularly. Dirt can lead to damage or the build up of odours.

- Always clean the appliance exactly as indicated in the operating instructions.
- Always ensure the appliance is switched off before cleaning or replacing parts.
- There is a risk of fire if cleaning is not carried out as described in these operating instructions.
- Make sure no water penetrates inside the device when cleaning. Do not use a steam cleaning appliance to clean this appliance. The steam could reach electrical components and cause a short circuit.
- In areas which may be subject to infestation by cockroaches or other vermin, pay particular attention to keeping the machine and its surroundings in a clean condition at all times. Any damage which may be caused by cockroaches or other vermin will not be covered by the machine warranty.

## 2.2 Safety Instructions - Installation

- In order to avoid any potential hazard, the installation instructions must be followed.
- Observe all regional regulations for the installation of ventilation systems.
- During installation, maintenance and repair work, the appliance must be disconnected from the mains electricity supply. It is only completely isolated from the electricity supply when:
  - the mains circuit breaker is switched off, or
  - it is switched off at the wall socket and the plug is withdrawn from the socket.
- Do not damage the refrigerant circuit.
- After the wine cabinet is installed in place, the plug shall be easily accessible to facilitate the removal of the cooler plug in case of any accident.

- Do not pull the mains connection cable but the mains plug to disconnect your appliance from the mains electricity supply.
- Do not connect the appliance to the mains electricity supply by a multi-socket unit or an extension lead.
- Extension leads are a fire hazard and do not guarantee the required safety of the appliance.
- Tampering with electrical connections or components and mechanical parts is highly dangerous to the user and can cause operational faults. Only open the housing as described in the instructions given in "Installation" section of this booklet. Under no circumstances should any other parts of the housing be opened.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

- THIS APPLIANCE MUST BE PROPERLY EARTHED. It is most important that this basic safety requirement is present and tested regularly and, where there is any doubt, the household wiring system should be inspected

by a qualified electrician.  
LeCavist cannot be held liable for noncompliance with these instructions, resulting from incorrect or improper use or operation.

---

## 2.3 Correct use and Operation

- For safety reasons, this appliance may only be used after it has been installed.
- Reliable and safe operation of this appliance can only be assured if it has been connected to the main electricity supply.
- Before using the appliance, ensure that all packaging materials are removed from the appliance and make sure that the connection data on the data plate [voltage (V) and frequency (Hz)] indicated on the appliance corresponds to the voltage and frequency of the power supply in your household. Consult a qualified electrician if in doubt.
- DO NOT store or spray flammable materials in the appliance or near this appliance while it is in operation (e.g. aerosols).
- Prevent water ingress. Never sprinkle or flush the cooler using water, place the cooler in an area exposed to moisture water sprinkling, or fill the cooler with water, so as to avoid impairment of the electric insulation of the cooler. Furthermore, failing to follow such requirements may lead to electric shock and fire, or other accidents.

- After the wine cabinet is put into operation, never touch its inner surface, especially when your hand is wet; otherwise the skin may stick onto the inner surface to get injured.
- Regularly clean surfaces that can come in contact with food and accessible drainage systems. If the refrigerating appliance is left empty for long periods, switch off, clean, dry, and leave the door open to prevent mould developing within the appliance.
- Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.
- Cracks, fissures or fractures in the panels can damage the underlying electronics. Switch off and disconnect the appliance immediately.



### WARNING

The refrigerant isobutane (R600a) is contained within the refrigerant circuit of the appliance, a natural gas with a high level of environmental compatibility, which is nevertheless flammable. During transportation and installation of the appliance, ensure that none of the components of the refrigerant circuit becomes damaged.

---

## 2.4 Disassembling and Disposal of the Appliance

(see the “Environmental Tips” section for best practices on disposing of this appliance).

The device must only be disassembled by trained specialists who are familiar with and comply with the standard national regulations and supplementary regulations of the local utility companies.

Work on electrical components must only be conducted by trained electrical personnel.

---

## 2.5 Accessories and Spare parts

Incorrect components can lead to personal injury or damage to the appliance. Only use original Lecavist spare parts for repairs.

Modifications, additions or alterations to the appliance can lead to safety risks. If spare parts or accessories from other manufacturers are used, the warranty will be invalidated, and Lecavist cannot accept liability.

Please check [www.lecavist.com](http://www.lecavist.com) for more information.


---

## 2.6 Use of Extension Cord


Avoid the use of an extension cord because of potential safety hazards under certain conditions. If it is necessary to use an extension cord, use only a 3-wire extension cord that has a 3-blade grounding plug and a 3-slot outlet that will accept the plug. The marked rating of the extension cord must be equal to or greater than the electrical rating of the appliance.

### 3. INSTALLATION INSTRUCTIONS

|                           |                                                 |
|---------------------------|-------------------------------------------------|
| Product model             | LEK14PV/LEK21PV/LEK33PV                         |
| Voltage/ frequency        | 220-240V~/50Hz                                  |
| Refrigerant/ weight       | R600a,21g/21g/23g                               |
| Volume                    | 50L/70L/90L                                     |
| Net weight                | 13kg/15kg/17kg                                  |
| Product dimension (WxDxH) | 445×470×500mm<br>445×470×675mm<br>445×470×830mm |
| Packing dimension (WxDxH) | 505×530×575mm<br>505×530×750mm<br>505×530×910mm |




**LEK14PV**



**LEK21PV**


- 1 Interior Light
- 2 Electronic Control Panel
- 3 Fan cooling
- 4 Wire Shelves wood trim
- 5 Double Pane Glass Door
- 6 Adjustable Leveling Legs

When selecting a location for your appliance you should make sure the floor is flat and firm, and the room is well ventilated. An average ambient temperature must be observed.




**LEK33PV**

|                   |                                                                                         |
|-------------------|-----------------------------------------------------------------------------------------|
| Brand             | Lecavist                                                                                |
| Reference         | LEK14PV / LEK21PV / LEK33PV                                                             |
| Defrost           | Automatic                                                                               |
| Climate class     | N/ST<br>This fridge is designed to be used in an ambient temperature of between 16-38°C |
| Temperature range | 2-18°C                                                                                  |
| Noise (dB)        | 43                                                                                      |




## 4. LOADING PLAN

LEK14PV




Comfort: 14 bottles




MAX: 15 bottles

LEK21PV




Comfort: 21 bottles



MAX: 27 bottles

LEK33PV



Comfort: 33 bottles

This wine cabinet is designed for versatile use. In addition to wine storage, it can be converted into a beverage fridge to chill cans, bottles, or non-alcoholic drinks.

### Temperature Control

#### 1. Recommended Settings

Wine Storage: 12-18°C


Beverage Cooling: 2-5°C

#### 2. WARNING

Beverage mode (2-5°C) is temporary; prolonged use may harm wine collections.

## 5. Drip Tray

Please install the drain tray on the upper part of the compressor as shown in the figure and correctly buckle it.



## 6. Wine Cabinet Features and Use



### Light

This button allows you to turn on / off the inside light. During normal use, the light needs to be in the off state.

### Increase temperature



Press the button once, the LED display will flash indicating the current temperature. Press again to set the temperature. Press once to increase the temperature by one degree. The flash stops after 5 seconds without action on your part, and the new temperature requested is recorded. The LED display then shows the actual temperature inside.

### Decrease temperature



Press the button once, the LED display will flash indicating the current temperature. Press again to set the temperature. Press once to decrease the temperature by one degree. The flash stops after 5 seconds without action on your part, and the newly set temperature is recorded. The LED display then shows the actual inside temperature.



### Mode Fahrenheit/Celsius

Press the button to switch the temperature display between Fahrenheit and Celsius.

## 7. CARE AND MAINTENANCE

> Before cleaning your appliance (something that should be done regularly), disconnect it by removing the plug or by pulling the fuse on the circuit.

> Before using your appliance for the first time and regularly after that, we recommend that you clean the inside and outside (front, side and top) with warm mixed with a gentle cleaning product. Rinse with clean water and allow drying before reconnecting. Do not use solvents or abrasives. When the appliance is switched on for the first time, there may be a residual odor. In that case, run the appliance empty for a few hours at the coldest possible temperature. The cold will kill any odors.

### 7.1 In case of a power cut

> Occasionally there may be power interruptions due to thunderstorms or other causes. Remove the power cord from AC outlet when a power outage occurs. When power has been restored, replug power cord to AC outlet. The unit will revert to the factory setting of 46°F after any power outage. Reset your temperature selection.

### 7.2 Moving your wine cabinet

Remove all items.

- > Securely tape down all loose items (shelves) inside your appliance.
- > Turn the adjustable leg up to the base to avoid damage.
- > Tape the door shut.
- > Be sure the appliance stays secure in the upright position during transportation. Also protect outside of appliance with a blanket, or similar item.

## 8. IN THE EVENT OF A BREAKDOWN

Despite the care, we take during production, a breakdown can never be totally ruled out. Before contacting your retailer's after-sales department, please check that:

- > The appliance is properly plugged in.
- > There is not a power cut in progress.
- > The breakdown is not one of those described in the table at the end of this manual.

**IMPORTANT:** If the power cable supplied is damaged, it must be replaced by the manufacturer, a service centre approved by the brand or the retailer. In all events, it must be replaced by qualified personnel in order to avoid any risk of injury.

**WARNING:** Do not use electrical appliances inside the food/ice storage compartments unless they are of the type recommended by the manufacturer.

**WARNING:** The maximum loading of the shelves (25kg) must not be exceeded.


## 9. TROUBLESHOOTING GUIDE

You can solve many common Wine Cabinet problems easily, saving you the cost of a possible service call. Try the suggestions below to see if you can solve the problem before calling the servicer.

| PROBLEM                               | POSSIBLE CAUSE                                                    | POSSIBLE SOLUTION                                                                                               |
|---------------------------------------|-------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
| The appliance does not work           | Power plug not connected to electrical outlet                     | Check the plug connecting it other appliance, or verify that the appliance is connected to the plug             |
|                                       | Supply cord is damaged                                            | Have supply cord replaced by the manufacturer, its service agent or similarly qualified persons.                |
| The appliance doesn't cool enough     | The door is too often opened or was left opened for a long time   | Close the door and do not open it too much frequently                                                           |
|                                       | Thermostat is not set correctly                                   | Set temperature with thermostat as described in this manual.                                                    |
|                                       | Appliance is located near heat sources.                           | Move appliance well away from heat sources.                                                                     |
|                                       | Stored beverages or other objects prevent proper closing of door. | Remove the items that may impact the door opening                                                               |
| Appliance is very noisy               | Back of the appliance is placed too close to the wall             | Keep a minimum distance of 10cm to the wall or other object                                                     |
|                                       | Appliance not in a stable position.                               | Bring appliance into a stable position by adjusting its feet. Make sure that all feet are firmly on the ground. |
| Condensation on outside of appliance. | Normal phenomenon in hot and humid environments.                  | Wipe appliance with a dry and soft cloth.                                                                       |

### Replacing the light

This appliance consists of light-emitting diodes (LEDs). This type of diode cannot be changed by the consumer. The lifetime of these LEDs is normally sufficient for no change to be made. If however, and despite all the care taken during the manufacture of your wine cabinet, the LEDs were defective, please contact your after-sales service for any intervention.



## 10. ENVIRONMENTAL TIPS

Observe all safety and warning information during operation (see the "General Safety Instructions" section).

### 10.1 Disposal considerations

The transport and protective packaging has been selected from materials which are environmentally friendly for disposal, and can normally be recycled.

Recycling the packaging reduces the use of raw materials in the manufacturing process and also reduces the amount of waste in landfill sites. Ensure that any plastic wrappings, bags etc. are disposed of safely and kept out of the reach of babies and young children. Danger of suffocation.



### 10.3 Caution : Risk of fire

Do not use the appliance near explosive or flammable vapours.

Do not store any explosive or flammable substances, like benzene, liquid gas or glue, in the appliance.

If gas flows out of the appliance, do not pull the power plug from the outlet as this can cause sparks and fire.

Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.

Warning: Risk of fire / flammable materials, take care to avoid causing a fire by igniting flammable material.

Warning: Blowing insulation gas.




### 10.2 Disposing of your old appliance

Electrical devices marked with this label may not be disposed of in domestic waste at the end of their service life.

Electrical and electronic appliances often contain valuable materials. They also contain specific materials, compounds and components, which were essential for their correct function and safety. These could be hazardous to human health and to the environment if disposed of with your domestic waste or if handled incorrectly. Please do not, therefore, dispose of your old appliance with your household waste.

Please dispose of those materials by contacting your local authorities and ask for the correct method of disposal. Please ensure that your old appliance poses no risk to children while being stored prior to disposal.

By disposing of this product in accordance with the regulations, you protect the environment and the health of those around you from negative consequences.



## 11. WARRANTY & AFTER SALES SERVICE

Observe all safety and warning information during operation (see the "General Safety Instructions" section).

In the event of a fault which you cannot remedy yourself, please contact LeCavist.

### 11.1 Warranty

The manufacturer's warranty for this appliance is 2 years.

### 11.2 After sales service

The contact details for LeCavist are given at the beginning and end of these instructions.

When contacting LeCavist, please quote the model and serial number of your appliance. These can be found on the data plate at the back of the Wine Cabinet.

### Record model & serial number

Model:.....

Serial Number:.....

Register your product [www.lecavist.com](http://www.lecavist.com)

### 11.3 Replacement of spare parts

Incorrect components can lead to personal injury or damage to the appliance. Use only genuine original Lecavist spare parts.

Modifications, additions or alterations to the appliance can lead to safety risks. If spare parts or accessories from other manufacturers are used, the warranty will be invalidated, and Lecavist cannot accept liability.

Please check [www.lecavist.com](http://www.lecavist.com) for more information.

# LIKE TO KNOW MORE?

For further information on all LeCavist products,  
or to obtain detailed dimension and installation  
information, phone or email our Customer Care  
team or visit our website: **[www.lecavist.com](http://www.lecavist.com)**

---

Operating and installation instructions:

**Osass Australia Pty Ltd.**  
**ACN 644 539 668**  
**ABN 28 644 539 668**

The distribution and duplication of this document, as well as the use and disclosure of its contents are prohibited unless expressly authorised.

These operating and installation instructions have been drawn up with the greatest of care. But it cannot be ruled out that subsequent technical modifications have not yet been incorporated or the relevant content has not yet been adapted. Please accept our apologies in this eventuality. An updated version can be requested from our team. Subject to printing errors and mistakes.

© LeCavist

All rights reserved.

---